## Pelstat Continuous Wrist-Strap And Bench Monitor

## **Product Images**



## Description

The Pelstat Wrist Strap On-Line Monitor continuously monitors whether the wrist strap or Earth is disconnected. The Wrist Strap Monitor draws static from the human body continuously and has an instant warning LED and alarm to warn of wrist strap failure

- Continuously monitors both user as well as the bench
- Fitted with standard banana socket for universal use
- 2 x 3.5mm jack plug for Earth Connection
- Test Range: 900k -35M
- 12V DC Power Supply
- CE Approved



controlled environments company superior standards in cleanroom control 509 Mitchelstown Road, Ballycoolin, Dublin D15 A58X, Ireland T: +353 91 756 400 E: sales@cec.ie W: www.cec.ie