Recycle bin

Product code: Bin01

Overview

The Skipper sack holder bin is designed for multi-purpose waste and recycling use. With a wealth of versatile attachments it can be used indoors and outdoors with the Skipper Post & Base system via a collar, the cord strap clip, the Skipper suction pad bracket and, for permanent fixing, the Skipper wall clip.

Key features

Product Specifications

Width: 338mm Height: 194mm

Depth: 376mm Weight: 1.1kg

Key selling points

- Versatile design allows the recycle bin to attach to almost any surface
- Available in a range of lid colours (orange, green, red, blue, silver)

 Connects to the post & base collar, cord strap clip, wall clip and suction pad bracket

- Holds up to 15KG
- Supplied with stickers to designate general waste or recycling use

2 recycle bins can be attached to the Skipper post and base system via the post & base collar



Q. What types of bag should be used with the recycle bin?

- A. You can use any standard sized bag (simply lift the outer and inner lid and tuck the bag into the groove.
- Q. What should I use the bin for?
- **A.** The bin is designed to be used in a range of sectors including cleaning & hygiene, utilities, facilities management and construction (up to 15KG weight)